TOETBO" ZTHH9860



FIG. 1

#3



FIG. 2



FIG. 3

Docket No. 2003P-000


80
START
82
RECEIVE MESSAGE FROM WCD INCLUDING MVSN
84
DECODE MESSAGE BASED ON MVSN OF MESSAGE
86
FORWARD MESSAGE TO DISPATCH STATION
88
WCD MVSN = NMC MVSN ?
YES
NO
92
WCD MVSN > NMC MVSN ?
YES
NO
94
DIRECT WCD TO ERASE MACRO DATABASE
96
SEND ALL MACROS TO WCD
98
SEND MESSAGE MACROS BASED ON WCD MVSN

FIG. 4



FIG. 5A



FIG. 5B



FIG. 5C



FIG. 5D



FIG. 5E



FIG. 5F

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1			

FIG. 6A

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1

FIG. 6B

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1
3	1	2			

FIG. 6C

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1
3	1	2	3	1	2

FIG. 6D

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1
3	1	2	3	1	2
2	1	3			

FIG. 6E

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1
3	1	2	3	1	2
2	1	3	2	1	3

FIG. 6F

NMC DATABASE			TMCT DATABASE		
MACRO NO.	VERSION NO.	MVSN	MACRO NO.	VERSION NO.	MVSN
1	1	1	1	1	1
3	1	2	3	1	2
2	1	3	2	1	3
1	2	4			

FIG. 6G